


ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0239

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THESE INSTRUCTIONS.

Hardware Package (included):



Mounting Strap (A)



Mounting Screw (B)



Wire Connector (C)



Fixture Mounting Screw (D)



Green Grounding Screw (E)



Lock Nut (F)



Ball Nut (G)



Loop Lock (H)






Installation Steps

Turn off the power at fuse or circuit box

- Thread two fixture mounting screws through the mounting strap, and then secure with two lock nuts. Adjust the length of the fixture mounting screws if necessary.
- Attach the mounting strap to the outlet box by using two mounting screws.
- Rod Connections:
 - Thread the fixture wire from the fixture through the lower rod, and then secure the lower rod onto fixture using the threaded pipe.
 - Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
 - Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the threaded pipe.
 - Thread the fixture wire through the loop and fixture canopy, and then secure the loop onto the upper rod using the threaded pipe.

Note: Length adjustable from 14" to 71". Use fewer rods if shorter length is desired.
- Take a loop lock, open the locking tube, then hook it onto the loop of fixture canopy and the loop of upper rod. Close back the locking tube of the loop lock.
- Pull out the source wires from the outlet box. Make wire connections using wire connectors as follows:
 - Connect the hot wire (usually black insulation) from the fixture to the black wire from the power source.
 - Connect the neutral wire (usually white insulation) from the fixture to the white wire from the power source.
 - Attach the fixture grounding wire (usually green insulation or bare wire) to the mounting plate with the green grounding screw. Then connect it to the house grounding wire with the wire connector.


Carefully put the wires back into the outlet box.



VAXCEL

171104

6. Attach the fixture canopy to the mounting strap by inserting the fixture mounting screws, and then secure it with two ball nuts.
7. Attach the glass shade onto the socket and tighten the glass shade with the metal pad and socket ring.
8. Install 1 x 60W max medium base bulb (not included) to the socket.
9. Angled mounting recommended for a vaulted or angled ceiling. (See Fig. 1)



Turn on the power at fuse or circuit box

The following parts are available for re-order if damaged or missing.


Spare Parts List:

| | | |
|----------------------------|---------------------------|--------------------|
| | | |
| Mounting Strap (A) | Mounting Screw (B) | Wire Connector (C) |
| | | |
| Fixture Mounting Screw (D) | Green Grounding Screw (E) | Lock Nut (F) |
| | | |
| Ball Nut (G) | | |

Mounting Hardware
5772MM (1 SET)

Glass Shade 9916CS

| | |
|---------------|--------------|
| | |
| 12"Rod 4644RR | 6"Rod 4645RR |
| | |
| 3"Rod 4646RR | |



A: 4-3/4"

B: 14~71"